


Installation bracket guide


Step 1

- Place and fix installation plate on the wall





Step 2

- Place the unit on top hooks – same installation process



Step 3



- Install the bracket according to the picture to installation plate – it can be placed on both sides of installation plate



Place the bracket according to the picture perpendicular to the wall

Step 4

- Use a bracket to support the unit – the attachment point can be hooks or the space between hooks on the bottom frame line




Step 5

- Work freely with piping when unit is fixed and you have open space
- After the work is done, remove the plastic bracket and complete the installation of the unit


Important notes

- The installation bracket can be used for wall-mounted indoor units with a weight of max. 18 Kg
- Can be used for RA/SA/VRV wall mounted units

Technical drawings



3P798914A



4P798929

Daikin Europe N.V. Naamloze Vennootschap Zandvoordestraat 300 · 8400 Oostende · Belgium · www.daikin.eu · BE 0412 120 336 · RPR Oostende (Publisher)

ECPEN26-016 07/26



The present publication is drawn up by way of information only and does not constitute an offer binding upon Daikin Europe N.V. Daikin Europe N.V. has compiled the content of this publication to the best of its knowledge. No express or implied warranty is given for the completeness, accuracy, reliability or fitness for particular purpose of its content and the products and services presented therein. Specifications are subject to change without prior notice. Daikin Europe N.V. explicitly rejects any liability for any direct or indirect damage, in the broadest sense, arising from or related to the use and/or interpretation of this publication. All content is copyrighted by Daikin Europe N.V.